



[Home](#)
[Bench Corner Cutter](#)
[Contact](#)

## Pedestal Corner Cutters and Bench Cutters Spare Parts



- 1 Link (Pedestal & Bench) 311
- 2 Head for Cutter (Pedestal & Bench) 301
- 3 Treadle Pedal (Pedestal) 308
- 4 Connecting Rod (Pedestal)
- 5 Red Clamp Holder (Pedestal & Bench) 306
- 6 Rocker Arm Lever (Pedestal) 310
- 7 Cutting Table (Pedestal & Bench) 305
- 8 Connecting Unit for Rod and Pedal (Pedestal) 312
- 9 Right Hand Guide (Pedestal & Bench) 303
- 10 Left Hand Guide (Pedestal & Bench) 304
- 11 Sliding Ram (Pedestal & Bench) 302
- 12 Hand Lever (Bench) C-13
- 13 Hex head screws for the table base (Pedestal & Bench)
- 14 Clamp Spring (Pedestal & Bench)
- 15 Return Spring (Bench)
- 16 Return Spring (Pedestal) (Not Shown)
- 17 Clamp
- 18 Pedestal Base
- 19 Top Knife Screw
- 20 Bottom Knife Screw
- 21 Clamp Hold Down Assembly, includes 5, 14 and 17 (Pedestal & Bench)

Craftsmen Machinery Co., 840 Main St., Suite 208, Millis, MA 02054 Phone: (508) 376-2001 FAX: (508) 376-2003  
[sales@craftsmenmachinery.com](mailto:sales@craftsmenmachinery.com)